



## **Configuring the Nextel Motorola Razor V3m for use with VRS Networks and the TSC2**

### **Motorola i335**

1. With the phone turned on press menu button to left of the OK button.
2. Highlight the Bluetooth icon.
3. Press the OK button.
4. Scroll down and highlight Setup.
5. Press the OK button.
6. Highlight Power
7. Press the OK button.
8. Highlight On.
9. Press the OK button.
10. Bluetooth is now turned on.
11. Press the top right button to go back.

### **TSC2**

1. Turn on the TSC2 by pressing and releasing the power button at the bottom left of the keyboard.
2. Tap on Start at the top left of the screen.
3. Tap on Settings.
4. Tap on the Connections tab located at the bottom of the screen.
5. Tap on the Bluetooth icon.
6. Tap on the check box to Turn on Bluetooth.
7. Tap on the Devices tab at the bottom of the screen.

### **Motorola i335**

1. Highlight Find Me.
2. Press the OK button.
3. Your phone is discoverable for 1 minute.

### **TSC2**

1. Tap on New Partnership.
2. You will see the TSC2 searching for Bluetooth devices.
3. You should see Motorola Phone.
4. Tap on Motorola Phone to highlight it.
5. Tap on Next.
6. You are prompted to enter a Passkey.
7. Enter 0000 for the Passkey.
8. Tap Next.

### **Motorola i335**

1. You will be prompted to Bond with TSC2 with its Serial Number.
2. Press the top left key for Yes.
3. Enter 0000 for the Passkey on the Razor.
4. Press the top left key for OK.
5. Highlight Device History.
6. Press the OK button.
7. Press the top left key for Edit..
8. Highlight Access.
9. Press the OK button.
10. Highlight Automatic.
11. Press the OK button.
12. Press the top right key 3 times for Back to return the main phone menu.

### **TSC2**

1. Verify the Check Box for Dial-Up Networking is checked.
2. Tap Finish.
3. Tap on OK at the top right of the screen.

### **Creating a Network/Dial-up Connection on the TSC2**

1. Tap on the Connections icon.
2. Tap on Add a new modem connection under My ISP.
3. Enter Razor for the Name of the Connection.
4. Tap on the drop down list for Select a Modem.
5. Select Bluetooth from the drop down list.
6. Tap on Next.
7. Tap on Motorola Phone to highlight.
8. Tap on Next.
9. Enter S=2 for the phone number.
10. Tap on Next.
11. User Name – Leave Blank.
12. Password – Leave Blank.
13. Domain – Leave blank.
14. Tap on Finish.



15. Tap OK at the top right of the screen.
16. Tap on X at the top right of the screen to return to the desktop of the TSC2.

### **Testing Your Internet Connection between the Phone and the TSC2**

1. Tap on Start.
2. Tap on Settings.
3. Tap on Connections.
4. Tap on Manage existing connections under My ISP.
5. Tap and hold on your connection.
6. Tap on Connect.
7. The Network Log On screen appears.
8. Tap the check box to select Save Password.
9. Tap OK.
10. The “connecting” window will appear and dial the number.
11. When the window disappears, you are connected to the internet.
12. To disconnect tap on the icon to the left of the speaker icon at the top of the screen.
13. Tap on disconnect.

**If your connection is not successful, check with Nextel to make sure your plan is correct.**