



Sharing Measure Codes Groups between Data Collectors

The groups, and the codes within each group, are stored in a Measure Codes Database file (*.mcd). If you use a feature and attribute library, the Measure Codes Database file (*.mcd) is tied to that feature and attribute library and has a matching name. If you use the same feature and attribute library on other controllers, you can copy the *.mcd file to use in the other controllers. To use the feature and attribute library *.mcd file, you must assign the feature and attribute library to the job.

If you do not use a feature and attribute library, a [Default.mcd] file is created. The [Default.mcd] file can also be copied to other controllers. When the Trimble Survey Controller software does not have a feature and attribute library assigned to a job, the [Default.mcd] file is used in Measure codes.

The (*.mcd) file is located in the Trimble Data Folder on your controller.

To copy and paste between data collectors see the Tech Tip – Transferring Data with a Thumb Drive on at TSC2 (Ranger).